

Skirt Hang'R

Metal Skirting Bracket

Installation Instructions



**Galvanized
Part #43779**

Side Method #1 - For attachment of skirting back rail directly to the *Skirt Hang'R*.

Install the *Skirt Hang'R* to the outer rim joist thru the slots in the flat top of the bracket using 1" long #8 screws supplied with most skirting hardware kits. We suggest popping a chalk line to the under side of the home to help keep the brackets in line. Spacing of *Skirt Hang'R* should be 16" to minimize oil canning effect of vinyl back rail.

Side Method #2 - For attachment of optional backing support to *Skirt Hang'R*.

Install the *Skirt Hang'R* to the outer rim joist thru the slots in the flat top of the bracket using 1" long #8 screws supplied with most hardware kits. We suggest popping a chalk line to the under side of the home to help keep brackets in line. Spacing of *Skirt Hang'R* can be 4' when using a minimum of 1" X 4" optional bracing for attachment. Attach backing support to *Skirt Hang'R* using holes provided.

End Method #1 - Standard Beam Attachment

Attach *Skirt Hang'R* under the lip of the beam by making a starter hole with a 5/32" drill bit and using #8 X 3/4" self-tapping screws. Continue adding *Skirt Hang'R* brackets as required for proper spacing of direct or backing support attachment, attach backing support to *Skirt Hang'R* in holes provided.

End Method #2 - Alternative Attachment

Using the flat top of the *Skirt Hang'R*, line up the edge of the bracket and the gap where the bottom of the wall and the beam come together. Insert the flat edge of the *Skirt Hang'R* in the gap and use a hammer to tap until the flush with beam. Continue adding *Skirt Hang'R* brackets as required for proper spacing of direct or backing support attachment, attach backing support to *Skirt Hang'R* in holes provided.

Completing Skirting Installation

1. Snug the screws to the joist but don't tighten at this time. Make sure the longer downward leg is facing towards the outside of the home.
2. Attach back rail to *Skirt Hang'R* or optional supports with screws thru the oblong slots in the back rail and snug up to *Skirt Hang'R* in holes provided or straight to supports. Do not tighten completely as the vinyl rail needs expansion and contraction room.
3. When finished with side of unit make sure *Skirt Hang'R* brackets are aligned straight and adjust as needed, and tighten to rim joist. Then move to the end of the home and continue.