Better Bath Components Alternative Tub Ledger Support Installation Instructions

This tub ledger support is intended to be an optional replacement for all or part of the wooden or OSB supports required for Better Bath Components flanged tubs.

LEDGER SUPPORT INSTALLATION:

- Reference tub installation instructions to determine alcove dimensions for the tub being installed. Allow additional 3/16" for inclusion of Tub Ledger Kit when designing alcove.
- Determine required length of ledger support. Kits are available pre-cut to necessary lengths. If necessary, trim ledger support to length.

- The ledger support(s) must be installed to the tub prior to tub installation. NOTE: Assure ledger support is centered when installed against the tub flange. Do not allow space between ledger support and flange.
 - a. Take note of the position of wall studs in relation to edges of tub.
 - b. Assure area on tub where tape will be applied is clean and dry.
 - Remove release paper from foam tape on ledger support.
 - d. With the long leg of the support in the vertical position, overlapping at least two wall studs, apply ledger support to the underside of the tub and press firmly into place.
- Refer to "Securing Flanges To Wall" in the specific tub installation instructions, and proceed with tub installation.