

Style Crest, Inc. Fiberglass Steps

INSTALLATION GUIDELINES

- 1) Place your Style Crest Fiberglass Step in front of the doorway that you wish to enter. The surface on which you place the step must be smooth, dry, solid, absolutely flat and level.
- 2) Place the step as close to the doorway as possible.
- 3) Size your step so there is no greater distance than seven inches from top of platform to threshold of the door. (The true distance from the platform of the step to the threshold of the door should be no greater than the height of the shortest riser. In most cases it would be seven inches).
- 4) Bolt on either side rails, or a side and back rail (see rail installation instructions).
- 5) Make sure the surface below the step is absolutely level.

WARNING: Failure to set and level the step properly may result in injury.

- 6) Keep your step clean, dry and free of ice. The steps may be cleaned with any household detergent. You may use salt to keep the step free of ice.

WARNING: Follow these guidelines. They are necessary to attain the maximum pleasure, performance and safety from your step.



Step/1(8125) rev5/05

ALUMINUM RAIL INSTALLATION INSTRUCTIONS

TOOLS NEEDED: 7/16 BOX END WRENCH, DRIFT PUNCH

1. Determine if you will be using a left or right hand mounting configuration. Remove appropriate caps from threaded inserts in step side.
2. Using 2 ea. 1-3/4" bolts and 2 ea. 1/4" fender washers, bolt back rail post to side of step threading 1-3/4" bolts into threaded inserts in step. Do not tighten completely.
3. If using a 3 post railing, follow step 2 for the center railing post also. If railing holes do not line up exactly with step inserts, railing can be adjusted to fit by gently pulling by hand the center railing post, or using a drift punch, insert punch into top hole and adjust so the railing post holes line up with the inserts.
4. Using 2 ea. 1-3/4" bolts and 2 ea. 1/4" fender washers, bolt front post to side of step.
5. Once all bolts are started into inserts, tighten all bolts securely.

Back Rail Models: Using 2 ea. 1-3/4" bolts and 2 ea. 1/4" fender washers, attach back rail to rear of step with the provided inserts. Snap top cap onto side rail and back rail at the joining point. Tighten all bolts securely. Using "L" bracket supplied, attach to upper side and back rail post with 2 ea. 1-3/4" bolts, 2 ea. 1/4" fender washers, and 2 ea. nuts. Insert 1-3/4" bolt through "L" bracket into posts, attach 1/4" fender washer and nut to bolt.

Literature Item Number **306001004**